

Introduction

S E C T I O N 1

The Escort5580 Voice Assisted Security Control provides easy to understand audible information about the status of your security system, and makes operation simple by prompting the user through each operation. In addition, you can use the Escort5580 to control various Home Automation items.

The Escort5580 allows any touch-tone telephone to act as a keypad for your security system. The telephone could be any telephone that is on the same line as your security system, or an outside telephone which may be used to call the security system.

Some optional features described in this manual may not be available on your security system. You will not hear the voice prompts for any option that is not activated on your system.

In this manual, the voice messages are printed in bold and are enclosed in quotes, as shown here:

“Enter your access code”

Your installer may have programmed labels for the Escort to announce when it refers to things such as zones and partitions (e.g. you may hear "East wing" instead of "Partition 2"). Prompts that your installer may have changed are written in brace brackets, as shown here:

“To Select {Partition 2}, press [2].”

When instructed to press a key or keys to perform an operation, symbols for the keys will be enclosed in square brackets, as shown here:

Enter [★]

1.1 About Your Security System

Your DSC security equipment has been designed to give you the greatest possible flexibility and convenience. To fully benefit from the features of your security system, you should read this manual and the Instruction Manual provided with your system very carefully. Have your installer instruct you on system operation and on which features have been activated on your system. All users of the system should be instructed on its use. Fill out the System Information page in your Security System Instruction Manual and store it with the manual in a safe place for future reference.

IMPORTANT NOTE: A security system cannot prevent emergencies. It is only intended to alert you and, if included, a central station of an emergency situation. Security systems are generally very reliable but they may not work under all conditions and they are not a substitute for prudent security practices or life and property insurance. Your security system should be installed and serviced by qualified security professionals who should instruct you on the level of protection that has been provided and on system operation.

1.2 General System Operation

Your security system is made up of a control panel, one or two regular keypads (one for each partition of your system), the Escort5580, and various detection devices. The control panel will be mounted out of the way in a utility room or in the basement. The metal cabinet contains the system electronics, Escort5580 Voice Assisted Security Control, fuses and stand-by battery. There is normally no reason for anyone but the installer or service persons to have access to the control panel.

The security system has several zones—areas (e.g. rooms) or barriers (e.g. doors, windows) of protection monitored by one or more detection devices (e.g. motion detectors, door contacts, glassbreak detectors or shock sensors).

The regular keypad is an important part of your security system. It is used to send commands to the system and to display system information. Even though a telephone and the Escort5580 can be used to operate your system, the telephone will not automatically display or indicate system status or zones in alarm. Therefore, it is essential that a regular keypad be placed in a location that is accessible to all users of the security system, and that it be checked regularly for any changes in system status.

1.3 Access Codes

When using a telephone to operate your security system, you will first have to enter a Telephone Access Code, and then use the same Access Codes you use with the regular keypad. The Master Code and other access codes programmed on your system work exactly as if you were using a regular keypad. Refer to your system's instruction manual for further information on access codes.

NOTE: It is recommended that Duress Codes not be used with the Escort5580.

1.4 Audio Help

If your security system has an audio matrix module (PC59XX and intercom stations) connected to it, the Escort5580 can provide step-by-step audio instructions through the intercom stations. You can access the help function in one of two ways, depending on how your installer has programmed the "Help" button on your keypads:

General Audio Help

1. Press the "Help" function key on the keypad
2. The Escort5580 will page all intercom stations.
3. Press the Page/Answer button on one of the stations (this button must be pressed within 5 seconds for the feature to work). This links the stations to the Escort5580. The Escort5580 announces audio help prompts over the intercom stations.

Identified Audio Help

1. Press the Help function key on the keypad
2. The Escort5580 announces audio help prompts over the intercom station beside the keypad.

NOTE: If a user is accessing the Escort locally over the telephone line, the Help function key will not work.

Accessing Your Security System

S E C T I O N 2

With the Escort5580 you can use a telephone (touch-tone only) to access your security system. This can be done either from a telephone on the premises (Local Access), or from a telephone off the premises anywhere in the world (Remote Access).

2.1 Local Access

Use this procedure to access your security system from a telephone that is on the same telephone line as your security system. No dial-in is necessary.

Pick up the telephone; you will hear a dial tone.

Enter your **Telephone Access Code**. The dial tone will stop and the system will announce:

"Hello."

The system will then prompt:

"Enter your access code."

Enter your [access code]. The system announces one or more messages to advise you of its status.

2.2 Remote Access

From any touch-tone telephone, first dial the number of your premises. If your premises have more than one line, be sure to call the number of the same line on which your Escort5580 has been installed. After a single ring, hang up, wait 10 seconds, and call again. On the second call, the system will answer after one or two rings and announce:

"Hello."

Now you must enter your **Telephone Access Code** within 10 seconds or the system will automatically hang up.

The system will then prompt:

"Enter your access code."

Enter your [access code] within 20 seconds or the system will hang up. The system will also hang up if 3 incorrect access codes are entered.

Once an access code has been entered, the system will announce one or more messages to advise you of its status.

NOTE: There is only one "Telephone Access Code". It is programmed by your installer. It is not the same as your system access code, which you also enter on your system keypad. More than one system access code may be programmed for use by different users of your system (see section 8—Programming Access Codes).

2.3 Receiving Incoming Calls

If the Escort5580 is being used on the premises at the same time as someone calls you, the system will announce:

"Attention, you have an incoming call. To receive the call, press [#] now."

To answer the incoming call, press [#]. To continue to use the Escort5580, don't press [#].

2.4 What is a Partition?

A partition is a group of zones which act independently of other groups of zones. Each partition acts as an independent alarm system. Partitions will have different access codes to arm and disarm them. The access codes assigned to one partition will not work on another partition. However, access codes can be assigned to more than one partition to allow someone to use one access code for several different partitions. Your installer will inform you how partitions and access codes have been assigned on your system.

NOTE: If you have a two-partition system, be sure to have your installer explain if your Escort5580 has been enabled to control one or both partitions.

2.5 If You Have a Two-Partition System

If you have a two-partition system, the Escort may prompt you to select a partition after entering your access code (as in Section 2—Accessing Your Security System). You will have to select a partition only if:

- your Escort5580 has been enabled to control both partitions
- the access code you enter has been programmed to access both partitions

If both of these are the case, the system will prompt you to select a partition as follows:

“To Select {System}, press [1].”

“To Select {Partition 2}, press [2].”

(“{System}” in this case refers to Partition 1)

Press [1] or [2], to select a partition.

The system will announce the status of the selected partition.

NOTE: Prompt words enclosed in brace brackets, “{ },” refer to labels. The system will announce the enclosed word by default unless it has been programmed to announce a specific label (e.g. you might hear “East Wing” instead of “{Partition 2}”).

2.6 Fire, Auxiliary and Panic Alarms

Your installer may have set up your system so that you can send a Fire, Auxiliary or Panic alarm at the press of a button. If so, using your telephone, you can:

- send a Fire alarm by pressing and holding [1] on your telephone for 2 seconds
- send an Auxiliary alarm by pressing and holding [2] on your telephone for 2 seconds
- send a Panic alarm by pressing and holding [3] on your telephone for 2 seconds.

Ask your installer for more information.

NOTE: If the keypad lockout has been triggered by the entry of a number of incorrect access codes, the Fire, Auxiliary and Panic alarm buttons will not work.

Arming and Disarming

S E C T I O N 3

With the Escort5580, you can use a telephone to arm your system/partition (so that alarms, or other devices, will be activated when a zone on your premises is breached, such as when an Entry-Exit Door is opened). This can be done either locally or remotely. Similarly, you can use a telephone to disarm the system/partition.

NOTE: DO NOT use a telephone with a redial button to arm or disarm your system.

3.1 Away Arming

NOTE: When arming your system/partition from a remote telephone, the system/partition will automatically be armed in Stay mode. (See section 3.2, below.)

Access your system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

If the system/partition is ready to be armed, the system will prompt:

"{System} is OFF.

To turn ON, enter your access code."

Enter your [access code]. The system will then announce:

"Turning {System} ON. Exit Delay in progress.

To turn OFF, enter your access code."

If the system/partition is not ready to be armed, the system will prompt:

**"{System} is open. {Zone XX}
Secure before turning ON."**

When the "Secure before turning on" message is heard, ensure that any breached zones on the system/partition are secure (e.g. by closing any open doors that the system/partition monitors) before trying to arm the partition.

NOTE: Depending on the model of control panel you have, you may be able to toggle Stay/Away zones on or off after your system has been armed. See your system's Instruction Manual for more information.

3.2 At-Home Arming

At-Home Arming allows you to arm the system/partition and remain on the premises. When a system is at-home armed, certain zones (Stay/Away zones) will not be armed, so that you can move freely in certain areas of the premises. Your installer should tell you which zones are Stay/Away zones. At-Home Arming also cancels the Entry Delay (see the Instruction Manual of your control panel) on the Entry-Exit Doors so that an alarm will sound *immediately* if the Entry-Exit Door is opened.

When the system prompts:

"{System} is OFF.

To turn ON, enter your access code."

Activate the Stay Arming feature by pressing [★]. The system will then prompt:

"To turn the system ON without Entry Delay, press [9],"

Press [9]. The system will prompt:

"Enter your access code."

Enter your [access code]. The system announces:

“Turning {System} ON without Entry Delay. Exit Delay in progress”

After exit delay expires, the selected partition will now be armed in At-Home Mode. Opening the entry-exit door will now sound an immediate alarm.

NOTE: Depending on the model of control panel you have, you may be able to toggle Stay/Away zones on or off after your system has been armed. See your system's Instruction Manual for more information.

3.3 Disarming

IMPORTANT NOTE: If you return to the premises and find that an alarm has occurred while you were away, it is possible that an intruder may still be on the premises. Do not enter the premises. Go to the nearest telephone and contact the authorities.

To disarm your system/partition, first access the system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

If the selected partition is armed, the system prompts:

“{System} is on. To turn off, enter your access code.”

Enter your [access code]. The system announces:

“{System} is off.”

If there were no alarms while the system/partition was armed, the system announces:

“No alarms in memory.”

If there were any alarms when the system/partition was armed, the system can announce how many there were and which zones were breached (see Section 3.5—Alarm Memory).

When the system/partition is disarmed, additional messages may be announced to advise you of its status, or to allow you to select another partition.

3.4 If An Alarm Sounds While You Are Home

There are two possible types of alarm, a Fire Alarm and an Intrusion Alarm. Each can have its own distinctive tone. Your immediate response will depend on which has been sounded. You should have these responses planned ahead of time.

- **Fire Alarm**

Your installer will inform you if fire detection equipment has been installed and activated on your system.

Fire alarms will sound with a pulsing tone. If a fire alarm sounds, follow your emergency evacuation response plan immediately. Refer to the guidelines for Family Escape Planning (Section 8.2) at the back of this manual to construct your response plan.

NOTE: Delay fire zones will not go into alarm while the Escort5580 is being accessed.

- **Intrusion Alarm**

Intrusion alarms will sound with either a continuous or pulsed tone (ask your installer). If an intrusion alarm sounds, an intruder may still be on the premises. Go to a safe place immediately. If you are certain that the premises are safe, you can silence the alarm by disarming the system.

If the alarm was unintentional, notify your central station and/or the local authorities immediately to prevent an unnecessary response.

You can determine the cause of an alarm by reviewing the alarm memory (see Section 3.5—Alarm Memory). Once the alarm has been cleared (i.e. zones secured) and the system disarmed, your system/partition can be re-armed.

3.5 Alarm Memory

Your system will record any alarms that occurred while the system/partition was armed. If an alarm occurred while the system/partition was armed, upon disarming it the following message will be announced:

“There are (number) alarms in memory: {Zone XX}.”

To hear again the zones that went into alarm, press [★]. The system will prompt:

“For Alarm Memory, press [3].”

Press [3], and the system will indicate the zones in Alarm Memory:

***“There are (number) alarms in memory, {Zone XX}.
To exit, press [#].”***

When finished reviewing the zones in alarm memory, press [#] to return to the other system status messages.

3.6 Bypassing Zones

Zones may be bypassed when access is required to part of a protected area while the system/partition is armed. Once a system is armed, bypassed zones will not trigger an alarm when they are breached.

You can only set a zone to be bypassed while the system is disarmed.

To bypass zones, first access the security system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

The system will prompt:

“{System} is OFF.

To turn ON, enter your access code.

For options, press [★].”

Press [★]. The system will announce the list of System Options. The system prompts:

“For Zone Bypassing, press [1].”

Press [1].

If your system requires that you enter an access code to bypass zones, the system will prompt:

“Enter your access code.”

Enter your [access code].

The system will announce the Zone Bypass menu:

“There are (number) zones bypassed: {Zone XX}, etc...”

To exit, press [#].”

To bypass a zone, enter the one- or two-digit zone number. The system will announce:

“ There are (number) zones bypassed: {Zone XX}, etc...”

To exit, press [#].”

You can now arm the system/partition at any time (see Section 3.1—Away Arming) and the zone(s) you selected will be bypassed. Zone bypasses are automatically removed each time the system/partition is disarmed and must be reapplied before the next arming. For security reasons, your installer may program your system to prevent the bypass function from affecting certain zones.

Trouble Conditions

S E C T I O N 4

The control panel continuously monitors a number of possible trouble conditions. If one or more of these conditions occur, the regular keypad will beep twice every ten seconds. There is no indication on a telephone until the system is accessed.

To hear the trouble conditions present on your system/partition disarm the system (depending on the control panel you have, your system may allow you to enter the Trouble menu without first disarming the system/partition).

Access the security system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

Press [★]. You will hear the prompt:

“ For System Troubles, press [2].”

Press [2] and the system will announce one or more of the trouble conditions from the list below, if any are present. If no trouble conditions are present, the system will announce:

“ There are NO System Troubles.

To exit, press [#].”

The following describes the various trouble conditions that your system might announce:

<i>Announcement:</i>	<i>Problem and how it should be addressed:</i>
<i>“Service is required”</i>	If this message and no other trouble condition is announced, call for service.
<i>“AC Power Trouble.”</i>	Electrical power to the system has been interrupted. Check your fuse box or circuit breaker to ensure that the electricity supply for the system is on. If this does not correct the problem, call for service.
<i>“Phone line trouble.”</i>	Your system has detected a problem with the telephone line. If this problem does not correct itself, or happens frequently, call for service.
<i>“Communication trouble.”</i>	Your system has been unsuccessful in communicating an event to your central station. If you hear this message, call for service immediately.
<i>“ Zone Fault, press [5].”</i>	Your system has detected a Zone Fault on one or more zones. Press [5], and the system will announce which zones have a fault. If you are unsure of how to clear a zone fault, call for service.
<i>“Zone tamper, press [6].”</i>	Your system has detected a Zone Tamper on one or more zones. Press [6] and the system will announce which zone(s) have tampers. If you are unsure how to clear the zone tamper, call for service.
<i>“Device low battery, press [7].”</i>	Your system has detected that one or more of the wireless devices on the system has a low battery. Press [7], and the system will announce which devices have a low battery. Change the relevant batteries. If this does not correct the problem, call for service.
<i>“The time and date are incorrect.”</i>	If all power to the system is interrupted (AC and battery), the system clock and date will need to be reset. Press [★], then [6], and the system will provide prompts for you to enter the time and date. If you are unsure of the cause of the system power failure, call for service.

Setting Escort5580 Options

S E C T I O N 5

5.1 Setting The Time and Date

With the system disarmed (Section 3.3—Disarming), access the security system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

Press [★]. You will hear the prompt:

“ For Special Functions, press [6].”

Press [6]. The system will prompt:

“ Enter your Master Code.”

Enter the Master Code. The system will prompt:

“ For Time And Date, press [1].”

Press [1]. The system announces the current time and date, and then prompts:

***“To change the time, press [1].
To change the date, press [2].
To exit, press [#].”***

You may either:

- Press [1] to change the time. The system will prompt:

“ Enter four digits for 24-hour time.”

Enter the time in 24-hour clock format: 00 to 23 for the hour, and 00 to 59 for the minute.

-or-

- Press [2] to change the date. The system will prompt:

“ Enter six digits for the month, day, and year.”

Enter 01 to 12 for the month, 01 to 31 for the day, and 00 to 99 for the year.

Upon programming information into either of these two sections the system will again announce the Time and Date menu.

5.2 Volume Control

The volume of the system messages/prompts can be controlled with this feature.

With the system disarmed (Section 3.3—Disarming), access the security system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

Press [★]. You will hear the prompt:

“ For Special Functions, press [6].”

Press [6]. The system will prompt:

“ Enter your Master Code”

Enter the Master Code. The system will prompt:

“ For Volume Control, press [2].”

Press [2]. The system will then announce the current volume setting in one of three ways:

“ Volume is low. To change volume, press [1].”

“Volume is Medium. To change volume, press [1].”

“ Volume is high. To change volume, press [1].”

Press [1] to toggle through the volume levels until the desired volume is selected.

Press [#] to return to the Special Functions menu.

5.3 Speech Rate Control

The speech rate of the system messages/prompts can be controlled with this feature.

With the system disarmed (Section 3.3—Disarming), access the security system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

Press [★]. You will hear the prompt:

“ For Special Functions, press [6]”

Press [6]. The system will prompt:

“ Enter your Master Code”

Enter the Master Code. The system will prompt:

“ For Speech Rate control, press [3]”

Press [3]. The system will then announce the current speech rate in one of two ways:

“Speech rate is fast. To change speech rate, press [1].”

“Speech rate is slow. To change speech rate, press [1].”

Press [1] to toggle between the speech rates until the desired rate is selected.

Press [#] to return to the Special Functions Menu.

5.4 Door Chime Feature

When the Door Chime feature is enabled, a series of beeps will sound from the system's keypads when certain specified zones are opened or closed. Your installer will inform you if the Door Chime feature is enabled, and which zones on the system will activate the chime.

The Door Chime feature can be used to indicate the openings and closings of a door, such as a back door that is not always in sight.

To enable the Door Chime feature you should first disarm your system (Section 3.3—Disarming; depending on the control panel you have, your system may allow you to enable the Door Chime feature without first disarming the partition). Access the security system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

Press [★]. You will hear the prompt:

“ For Door Chime control, press [4].”

Press [4]. You will hear one of the following:

“Door Chime is ON/OFF”

To turn the door chime on or off, press [4] again. To exit, press [#].

Home Automation

S E C T I O N 6

The Home Automation feature allows you to control items (i.e. devices such as lights, appliances, etc.) with your security system.

Each item on your system may have been assigned to follow one or more preprogrammed schedules by your installer. For example, lights can be turned on and off at certain times of the day, and on certain days of the week. Scheduling can be used to give the premises the occupied appearance while you are away. Your installer should provide you with a list of which items have been programmed to follow which schedules, and the times that each schedule will follow. By knowing their schedules you will know when the various items on your system can be activated. To have schedules programmed or modified, contact your installer.

6.1 How to Access the Home Automation Menu

You can access the Home Automation menu when your system is either armed or disarmed. To use this menu, first access the security system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

Press [★]. The system will prompt:

“For Automation Control and User Programming, press [5].”

Press [5]. The system will prompt you with the Home Automation menu:

“For Automation Control, press [1].

For User Programming, press [3].

To exit, press [#].”

6.2 How to Use the Item Control Menu

From the Home Automation menu, press [1]. The system may prompt you to enter your access code. The system will then prompt you with the Item Control menu. This menu allows you to choose individual items (devices which are controlled by Home Automation) and to turn them ON or OFF:

Item Control Menu

“{Item XX}.”

“To turn ON, press [1].”

“To turn OFF, press [2].”

“For the next item, press [5].”

“For the previous item, press [6].”

“To select item using item number, press [7].”

“To exit, press [#].”

Function

Indicates the item or device selected.

Turns ON the item.

Turns OFF the item.

Advances to the next item.

Skips back to the previous item.

Lets you select another item by keying in its 2-digit number.

Returns to the Home Automation menu.

Dimming

The Dimming feature allows you to increase or decrease the brightness of an item, usually a light.

NOTE: This feature will only be enabled on items capable of dimming.

Items which have this feature enabled will have extra options in the Item Control menu. Only items with the Dimming feature enabled will have these options. If such an item is selected in the Item Control menu the system will announce the menu above with the addition of the following:

Item Control Menu	Function
<i>"To increase, press [3]."</i>	Increases the brightness.
<i>"To decrease, press [4]."</i>	Decreases the brightness.

NOTE: The Escort5580 allows [F], [A], and [P] alarms to be sent by holding down [1], [2], or [3], respectively, for two seconds. For this reason, do not hold down the [3] key to increase the brightness of an item. Press the [3] key in short intervals instead.

6.3 Mode Control

Modes give you control over groups of items. When a mode is turned ON, each of the items will automatically operate according to the schedule(s) assigned to them. For example, your installer may have programmed one of the modes as a {Vacation mode} that you can turn on to activate premises lights.

Your installer should provide you with a list of the items that have been assigned to each mode (if any modes are used). Your system has a maximum of 8 modes available.

To operate items according to modes, you must access the Mode Control menu.

To do this, first access the Home Automation menu, then press [2]. The system will prompt you with the following:

Mode Control Menu	Function
<i>"{Mode XX} is OFF/ON."</i>	Indicates whether the current mode is ON or OFF.
<i>"To change, press [1]."</i>	Press [1] to toggle the mode ON or OFF.
<i>"For the next Mode, press [2]."</i>	Press [2] to advance to the next mode.
<i>"For the previous Mode, press [3]."</i>	Press [3] to skip back to the previous mode.
<i>"To exit, press [#]."</i>	Press [#] to return to the Home Automation menu.

Use this menu to select any mode you want, and to turn it ON/OFF.

6.4 Global Item Control

Certain devices controlled by your system may be defined by your installer as Global Items. These items can be controlled together with a single command. For example, all of the lights on the premises may be all programmed as Global Items. You could then turn all the lights on or off at once. Your installer will inform you which automation items on your system are Global Items.

From the Home Automation menu, select Global Item Control by pressing [3]. The system will prompt you with the following:

***“To turn Global Items ON, press [1].
To turn Global Items OFF, press [2].
To exit, press [#].”***

6.5 Output Control Feature

The Output Control feature allows you to activate a programmable output on the main alarm control panel. This output can be used to temporarily open magnetically locked doors, or perform any function that requires a pulse of voltage to operate it. Up to 4 different output controls are available. Each can be programmed by your installer to activate a variety of devices. Ask your installer for more details.

You may activate an Output Control while the system is armed or disarmed. Access the security system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

Press [★]. You will hear the prompt:

“ For {Output Control}, press [7].”

Press [7]. You will hear the prompts:

“For {Output Control 1}, press [1].”

“For {Output Control 2}, press [2].”

“For {Output Control 3}, press [3].”

“For {Output Control 4}, press [4].”

Press the key corresponding to the Output Control you want to activate.

If an access code is required, you will hear the prompt:

“Enter your access code”

Enter your [access code]. The system will announce:

“{Output Control} in progress”

The system will return to the main menu.

6.6 Video Camera Triggering

The Escort5580 can be used to remotely control the triggering of video cameras. This can only be done with security systems that have cameras connected to them via a PC5108L module (ask your installer for more details). The Video Camera Triggering feature will cause cameras to take pictures according to a sequence (or script) that has been programmed in the PC5108L module.

To access this feature, access your system remotely (Section 2.2—Remote Access).

Press [★], then [8]. Your system will prompt:

"Enter your access code."

Enter your [access code]. The system will announce:

"Goodbye."

The system will then hang up so that the PC5108L can run the programmed script.

Programming Access Codes

S E C T I O N 7

The Access Code Programming feature allows you to program access codes (the Master Code may not be changeable with this feature) that will function on the security system as well as on the Escort. Your system will either have 4- or 6-digit access codes. Depending on what model of security system you have, you may have the option to program up to 37 of these codes.

Access codes are programmed as follows:

While disarmed, access your security system (Section 2—Accessing Your Security System) and select a partition (Section 2.5—If You Have a Two-Partition System).

Press [★]. The system will prompt:

“For Automation Control and User Programming, press [5].”

Press [5]. The system will then prompt:

“For Automation Control, press [1].

For User Programming, press [3].

To exit, press [#].”

Press [3]. Enter the [master code]. The system will then prompt:

“User Code Programming.

Enter the one-/two-digit User Number.

For User Option Programming, press [9].

Users X, Y and Z are programmed.

To exit, press [#].”

NOTE: Your system may or may not prompt you with the User Option Programming prompt. Please consult your security system’s User’s Manual for more information on User Options.

Enter the number that specifies which access code you want to program. The system will announce:

“Enter the new 4-/6-digit access code.

To exit, press [#].”

Enter the new code. You will again be prompted:

“User Code Programming.

Enter the one-/two-digit User Number.

For User Option Programming, press [9].

Users X, Y and Z are programmed.

To exit, press [#].”

If you wish to program another access code, enter the user number. If not, press [#] to return to the main menu.

Fire and Safety in the Home

S E C T I O N 8

Most fires occur in the home, and to minimize this danger it is recommended that a household fire safety audit be conducted and a family escape plan be developed.

8.1 Household Fire Safety

Check your home for the following potential hazards:

- Are all electrical appliances and outlets in a safe condition? Check for frayed cords, overloaded lighting circuits, and so on. If you are uncertain about the condition of your electrical appliances or household electrical service, have a professional evaluation.
- Are all flammable liquids stored safely in closed containers in a well-ventilated and cool area? Cleaning with flammable liquids, such as gasoline, should be avoided. Refer to product instructions, printed warnings and labels for information on using and storing hazardous materials safely.
- Are fire hazardous materials (such as matches) well out of the reach of children?
- Are furnaces and wood burning appliances properly installed, clean, and in good working order? If in doubt, have a professional evaluation.

8.2 Family Escape Planning

There is often very little time between the detection of a fire and the time at which it becomes deadly. Because of this, it is very important that a family escape plan be developed, practiced and followed.

1. Every family member should participate in developing the escape plan.
2. Study the possible escape routes from each location within the house. Since many fires occur at night, special attention should be given to the escape routes from sleeping quarters.
3. It is essential that escape from a bedroom be possible without opening the interior door.

Consider the following when making your escape plans:

- Make sure that doors and windows that open to the outside are easily opened. Ensure that they are not painted shut and that their locking mechanisms operate smoothly.
- If opening an exit or using an exit is too difficult for children, the elderly or handicapped, plans for rescue should be developed. This includes making sure that those who are to perform the rescue can promptly hear the fire warning signal.
- If the exit is above ground level, an approved fire ladder or rope should be provided, as well as training in its use.
- Exits on the ground level should be kept clear. Be sure to remove snow from exterior patio doors in winter. Outdoor furniture or equipment should not block exits.
- The family should have a predetermined assembly point where everyone can be accounted for; for example, across the street or at a neighbour's house.
- Once everyone is out of the house, call the Fire Department.
- A good plan emphasizes quick escape. Do not investigate first or attempt to fight the fire, and do not attempt to rescue belongings as this takes up valuable time. Once outside, do not re-enter the house. Wait for the fire department.
- Write the plan down and rehearse frequently, so that should an emergency arise, everybody will know what they are to do. Revise the plan as conditions change; for example, when there are more or fewer family members in the home, or if there are physical changes to the house.
- Make sure your fire warning system is operational by conducting weekly tests. If you are unsure about system operation, contact your installing company.
- It is recommended that you contact your local fire department and request further information on home fire safety and escape planning. If available, have your local fire prevention officer conduct an in-house fire safety inspection.

Glossary

S E C T I O N 9

- Access Code** A 4- or 6-digit code that allows users to access arming, disarming and other system functions. Different access codes may be assigned to different users.
- Item** Items are devices (e.g. lights, appliances, etc.) that can be controlled within the Home Automation feature of the Escort system. Such devices can be controlled using a touch-tone telephone.
- Mode** Modes give you control over groups of items programmed for scheduled or event initiated operation. When a mode is turned ON, each of the items will automatically operate according to the schedule(s) or panel events assigned to them.
Example: your installer may have programmed a "Vacation" mode that you can turn on to activate premises lights while you are away.
- Output Control** A control which allows you to activate an output on the main alarm control panel. This output can be programmed by the installer to activate a variety of devices (e.g. to temporarily open magnetically locked doors).
- Partition** A group of zones on the system which are armed/disarmed and controlled independently of other zones grouped into a separate partition. Each partition has its own keypad and can be assigned its own access codes.
- Telephone Access Code** . A 3-digit security code that must be entered when using a telephone to access the Escort system. The code must be entered whether calling locally (from a telephone on the premises and on the same line as the Escort) or remotely (from any other touch-tone telephone). Once access is gained to the Escort, a normal system access code is still usually required to access system functions.
- Zone** An area (e.g. a room) or barrier (e.g. a door) within the premises that is monitored by a detector (e.g. smoke detector, door/window contact, motion detector, glassbreak detector, etc.).

NOTES:

WARNING Please Read Carefully

System Failures

This system has been carefully designed to be as effective as possible. There are circumstances, however, involving fire, burglary, or other types of emergencies where it may not provide protection. Any alarm system of any type may be compromised deliberately or may fail to operate as expected for a variety of reasons. Some but not all of these reasons may be:

■ Inadequate Installation

A security system must be installed properly in order to provide adequate protection. Every installation should be evaluated by a security professional to ensure that all access points and areas are covered. Locks and latches on windows and doors must be secure and operate as intended. Windows, doors, walls, ceilings and other building materials must be of sufficient strength and construction to provide the level of protection expected. A reevaluation must be done during and after any construction activity. An evaluation by the fire and/or police department is highly recommended if this service is available.

■ Criminal Knowledge

This system contains security features which were known to be effective at the time of manufacture. It is possible for persons with criminal intent to develop techniques which reduce the effectiveness of these features. It is important that a security system be reviewed periodically to ensure that its features remain effective and that it be updated or replaced if it is found that it does not provide the protection expected.

■ Access by Intruders

Intruders may enter through an unprotected access point, circumvent a sensing device, evade detection by moving through an area of insufficient coverage, disconnect a warning device, or interfere with or prevent the proper operation of the system.

■ Power Failure

Control units, intrusion detectors, smoke detectors and many other security devices require an adequate power supply for proper operation. If a device operates from batteries, it is possible for the batteries to fail. Even if the batteries have not failed, they must be charged, in good condition and installed correctly. If a device operates only by AC power, any interruption, however brief, will render that device inoperative while it does not have power. Power interruptions of any length are often accompanied by voltage fluctuations which may damage electronic equipment such as a security system. After a power interruption has occurred, immediately conduct a complete system test to ensure that the system operates as intended.

■ Failure of Replaceable Batteries

This system's wireless transmitters have been designed to provide several years of battery life under normal conditions. The expected battery life is a function of the device environment, usage and type. Ambient conditions such as high humidity, high or low temperatures, or large temperature fluctuations may reduce the expected battery life. While each transmitting device has a low battery monitor which identifies when the batteries need to be replaced, this monitor may fail to operate as expected. Regular testing and maintenance will keep the system in good operating condition.

■ Compromise of Radio Frequency (Wireless) Devices

Signals may not reach the receiver under all circumstances which could include metal objects placed on or near the radio path or deliberate jamming or other inadvertent radio signal interference.

■ System Users

A user may not be able to operate a panic or emergency switch possibly due to permanent or temporary physical disability, inability to reach the device in time, or unfamiliarity with the correct operation. It is important that all system users be trained in the correct operation of the alarm system and that they know how to respond when the system indicates an alarm.

■ Smoke Detectors

Smoke detectors that are a part of this system may not properly alert occupants of a fire for a number of reasons, some of which follow. The smoke detectors may have been improperly installed or positioned. Smoke may not be able to reach the smoke detectors, such as when the fire is in a chimney, walls or roofs, or on the other side of closed doors. Smoke detectors may not detect smoke from fires on

another level of the residence or building.

Every fire is different in the amount of smoke produced and the rate of burning. Smoke detectors cannot sense all types of fires equally well. Smoke detectors may not provide timely warning of fires caused by carelessness or safety hazards such as smoking in bed, violent explosions, escaping gas, improper storage of flammable materials, overloaded electrical circuits, children playing with matches or arson.

Even if the smoke detector operates as intended, there may be circumstances when there is insufficient warning to allow all occupants to escape in time to avoid injury or death.

■ Motion Detectors

Motion detectors can only detect motion within the designated areas as shown in their respective installation instructions. They cannot discriminate between intruders and intended occupants. Motion detectors do not provide volumetric area protection. They have multiple beams of detection and motion can only be detected in unobstructed areas covered by these beams. They cannot detect motion which occurs behind walls, ceilings, floor, closed doors, glass partitions, glass doors or windows. Any type of tampering whether intentional or unintentional such as masking, painting, or spraying of any material on the lenses, mirrors, windows or any other part of the detection system will impair its proper operation.

Passive infrared motion detectors operate by sensing changes in temperature. However their effectiveness can be reduced when the ambient temperature rises near or above body temperature or if there are intentional or unintentional sources of heat in or near the detection area. Some of these heat sources could be heaters, radiators, stoves, barbeques, fireplaces, sunlight, steam vents, lighting and so on.

■ Warning Devices

Warning devices such as sirens, bells, horns, or strobes may not warn people or waken someone sleeping if there is an intervening wall or door. If warning devices are located on a different level of the residence or premise, then it is less likely that the occupants will be alerted or awakened. Audible warning devices may be interfered with by other noise sources such as stereos, radios, televisions, air conditioners or other appliances, or passing traffic. Audible warning devices, however loud, may not be heard by a hearing-impaired person.

■ Telephone Lines

If telephone lines are used to transmit alarms, they may be out of service or busy for certain periods of time. Also an intruder may cut the telephone line or defeat its operation by more sophisticated means which may be difficult to detect.

■ Insufficient Time

There may be circumstances when the system will operate as intended, yet the occupants will not be protected from the emergency due to their inability to respond to the warnings in a timely manner. If the system is monitored, the response may not occur in time to protect the occupants or their belongings.

■ Component Failure

Although every effort has been made to make this system as reliable as possible, the system may fail to function as intended due to the failure of a component.

■ Inadequate Testing

Most problems that would prevent an alarm system from operating as intended can be found by regular testing and maintenance. The complete system should be tested weekly and immediately after a break-in, an attempted break-in, a fire, a storm, an earthquake, an accident, or any kind of construction activity inside or outside the premises. The testing should include all sensing devices, keypads, consoles, alarm indicating devices and any other operational devices that are part of the system.

■ Security and Insurance

Regardless of its capabilities, an alarm system is not a substitute for property or life insurance. An alarm system also is not a substitute for property owners, renters, or other occupants to act prudently to prevent or minimize the harmful effects of an emergency situation.



• W A R N I N G •

This manual contains information on limitations regarding product use and function and information on the limitations as to liability of the manufacturer.

Instruction Manual

LIMITED WARRANTY

Digital Security Controls Ltd. warrants the original purchaser that for a period of twelve months from the date of purchase, the product shall be free of defects in materials and workmanship under normal use. During the warranty period, Digital Security Controls Ltd. shall, at its option, repair or replace any defective product upon return of the product to its factory, at no charge for labour and materials. Any replacement and/or repaired parts are warranted for the remainder of the original warranty or ninety (90) days, whichever is longer. The original owner must promptly notify Digital Security Controls Ltd. in writing that there is defect in material or workmanship, such written notice to be received in all events prior to expiration of the warranty period.

International Warranty

The warranty for international customers is the same as for any customer within Canada and the United States, with the exception that Digital Security Controls Ltd. shall not be responsible for any customs fees, taxes, or VAT that may be due.

Warranty Procedure

To obtain service under this warranty, please return the item(s) in question to the point of purchase. All authorized distributors and dealers have a warranty program. Anyone returning goods to Digital Security Controls Ltd. must first obtain an authorization number. Digital Security Controls Ltd. will not accept any shipment whatsoever for which prior authorization has not been obtained.

Conditions to Void Warranty

This warranty applies only to defects in parts and workmanship relating to normal use. It does not cover:

- damage incurred in shipping or handling;
 - damage caused by disaster such as fire, flood, wind, earthquake or lightning;
 - damage due to causes beyond the control of Digital Security Controls Ltd. such as excessive voltage, mechanical shock or water damage;
 - damage caused by unauthorized attachment, alterations, modifications or foreign objects;
 - damage caused by peripherals (unless such peripherals were supplied by Digital Security Controls Ltd.);
 - defects caused by failure to provide a suitable installation environment for the products;
 - damage caused by use of the products for purposes other than those for which it was designed;
 - damage from improper maintenance;
 - damage arising out of any other abuse, mishandling or improper application of the products.
- Digital Security Controls Ltd.'s liability for failure to repair the

product under this warranty after a reasonable number of attempts will be limited to a replacement of the product, as the exclusive remedy for breach of warranty. Under no circumstances shall Digital Security Controls Ltd. be liable for any special, incidental, or consequential damages based upon breach of warranty, breach of contract, negligence, strict liability, or any other legal theory. Such damages include, but are not limited to, loss of profits, loss of the product or any associated equipment, cost of capital, cost of substitute or replacement equipment, facilities or services, down time, purchaser's time, the claims of third parties, including customers, and injury to property.

Disclaimer of Warranties

This warranty contains the entire warranty and shall be in lieu of any and all other warranties, whether expressed or implied (including all implied warranties of merchantability or fitness for a particular purpose) And of all other obligations or liabilities on the part of Digital Security Controls Ltd. Digital Security Controls Ltd. neither assumes nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product.

This disclaimer of warranties and limited warranty are governed by the laws of the province of Ontario, Canada.

WARNING: Digital Security Controls Ltd. recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected.

Installer's Lockout

Any products returned to DSC which have the Installer's Lockout option enabled and exhibit no other problems will be subject to a service charge.

Out of Warranty Repairs

Digital Security Controls Ltd. will at its option repair or replace out-of-warranty products which are returned to its factory according to the following conditions. Anyone returning goods to Digital Security Controls Ltd. must first obtain an authorization number. Digital Security Controls Ltd. will not accept any shipment whatsoever for which prior authorization has not been obtained.

Products which Digital Security Controls Ltd. determines to be repairable will be repaired and returned. A set fee which Digital Security Controls Ltd. has predetermined and which may be revised from time to time, will be charged for each unit repaired.

Products which Digital Security Controls Ltd. determines not to be repairable will be replaced by the nearest equivalent product available at that time. The current market price of the replacement product will be charged for each replacement unit.

Table of Contents

1: Introduction	1
1.1 About Your Security System	1
1.2 General System Operation	2
1.3 Access Codes	2
1.4 Audio Help	2
2: Accessing Your Security System	3
2.1 Local Access	3
2.2 Remote Access	3
2.3 Receiving Incoming Calls	3
2.4 What is a Partition?	4
2.5 If You Have a Two-Partition System	4
2.6 Fire, Auxiliary and Panic Alarms	4
3: Arming and Disarming	5
3.1 Away Arming	5
3.2 At-Home Arming	5
3.3 Disarming	6
3.4 If An Alarm Sounds While You Are Home	6
3.5 Alarm Memory	7
3.6 Bypassing Zones	7
4: Trouble Conditions	8
5: Setting Escort5580 Options	9
5.1 Setting The Time and Date	9
5.2 Volume Control	9
5.3 Speech Rate Control	10
5.4 Door Chime Feature	10
6: Home Automation	11
6.1 How to Access the Home Automation Menu	11
6.2 How to Use the Item Control Menu	11
6.3 Mode Control	12
6.4 Global Item Control	13
6.5 Output Control Feature	13
6.6 Video Camera Triggering	14
7: Programming Access Codes	15
8: Fire and Safety in the Home	16
8.1 Household Fire Safety	16
8.2 Family Escape Planning	16
9: Glossary	17

NOTES: